VX520 RESTAURANT

	DISPLAY		<u>INSTRUCTIONS</u>
			INSERT OR SWIPE YOUR CARD
		SALE	PRESS [F2] SALE
		SETTLEMENT	
		REFUND	
SALE	AMOUNT:		ENTER AMOUNT AND PRESS [ENTER]
	TOTAL:		IF IT IS CORRECT, PRESS [F1] YES
		YES	
		NO	
	REMOVE CARD		REMOVE YOUR CARD
		SALE	PRESS [F2] SALE
		SETTLEMENT	
		REFUND	
	AMOUNT:		ENTER AMOUNT AND PRESS [ENTER]
	TOTAL:		IF IT IS CORRECT, PRESS [F1] YES
		YES	
		NO	
	SWIPE/INSERT		ENTER ACCOUNT NUMBER AND PRESS [ENTER]
	EXP DATE(MMYY):		ENTER EXPIRATION DATE AND PRESS [ENTER]
MANUAL SALE	CARD PRESENT		
MANUAL SALE		YES	•
		NO	PRESS [F1] YES, OR NOT PRESS [F2]NO
	[CARD PRESENT]		PLEASE IMPRINT CARD AND PRESS [ENTER]
	IMPRINT CARD		
	PRESS ENTER KEY		
	V-CODE		ENTER CVV2 CODE AND PRESS [ENTER]
	ADDRESS:		PRESS ADDRESS OR LEAVE BLANK AND PRESS [ENTER]
	ZIP CODE:		PRESS ZIP CODE OR LEAVE BLANK AND PRESS [ENTER]
		SALE	PRESS [REPRINT]
		SETTLEMENT	
		REFUND	
REPRINT			
		LAST RECEIPT	, ,
		ANY RECEIPT	OR [F3] ANY RECEIPT
	INVOICE NUMBER:		PRESS INVOICE NUMBER AND [ENTER]
		SALE	PRESS [TIP]
		SETTLEMENT	
		REFUND	
	RETRIEVE BY:		PRESS [F4] INVOICE #
		SRVR	
		AMT	
TIP ADJUST		ACCT	
		INV#	ENTER INVOICE NUMBER AND PRESS [ENTER]
	INVOICE NUMBER:		PRESS [F1] ADJ FOR THE TRANSACTION
	TRANSACTION DETAIL		OR PRESS [F3] NEXT FOR THE NEXT TRANSACTION
	TIP AMOUNT		ENTER TIP AMOUNT AND PRESS [ENTER
		NEW TIP	
			1
		SALE	PRESS [F3] SETTLEMENT
		SALE SETTLEMENT	PRESS [F3] SETTLEMENT
			PRESS [F3] SETTLEMENT
		SETTLEMENT	PRESS [F3] SETTLEMENT
SETTLEMENT	PASSWORD	SETTLEMENT	PRESS [F3] SETTLEMENT ENTER PASSWORD[16682] AND [ENTER]
SETTLEMENT	PASSWORD VERIFY TOTAL SALES	SETTLEMENT	
SETTLEMENT		SETTLEMENT	ENTER PASSWORD[16682] AND [ENTER]
SETTLEMENT		SETTLEMENT	ENTER PASSWORD[16682] AND [ENTER]

		INSERT OR SWIPE YOUR CARD
	SALE	PRESS [F2] SALE
	SETTLEMENT	FRESS [12] SALE
	REFUND	
	AMOUNT:	ENTER AMOUNT AND PRESS [ENTER]
	TOTAL:	IF IT IS CORRECT, PRESS [F1] YES
	YES	
	NO	
DEBIT	VISA DEBIT	PLEASE PRESS [F2] US DEBIT
	US DEBIT	
	//S TRANSACT MATH CITY RANK DERIT CARR	DI FACE DESCRIPTION OF DESCRIPTION O
	(IF TRANSACT WITH CITY BANK DEBIT CARD, MASTER CARD	PLEASE PRESS [F2] CITYBANK DEBIT
İ	CITYBANK CARD	
	CITES AIN OF THE	
	ENTER PIN ON PINPAD	
	REMOVE CARD	ENTER PIN NUMBER ON PINPAD
		REMOVE YOUR CARD
	SALE	PRESS [F4]REFUND
	SETTLEMENT	
	PASSWORD REFUND	ENTED DASSIMODD[46602] AND DDESS [FNITED]
	PASSWORD	ENTER PASSWORD[16682] AND PRESS [ENTER]
	AMOUNT:	ENTER AMOUNT AND PRESS [ENTER]
	TOTAL:	IF IT IS CORRECT, PRESS [F1] YES
REFUND	YES	,
	NO	
	CARD ENTRY OR	INSERT OR SWIPE YOUR CARD(OR ACCOUNT NUMBER)
	ACCOUNT NUMBER	
	(IF ENTER ACCOUNT NUMBER,	ENTER EXPIRATION DATE AND PRESS [ENTER]
	EXP DATE(MMYY):	
	SALE	PRESS [MORE]
	SETTLEMENT	- Ness [mone]
	REFUND	
	VOID	PRESS [F1] VOID
	FORCE	
	REFUND	ENTERDACCIMORDIACCOOLAND (ENTER)
	PASSWORD	ENTERPASSWORD[16682] AND [ENTER]
	VOID LAST TRANS?	IF IT WAS LAST TRANSACTION, PRESS [F1] YES
	YES	OR PRESS[F2] NO FOR ANY TRANSACTION
VOID	NO	
. 2		
	TRANSACTION DETAIL YES	CONFIRM TRANSACTION DETAIL,
	NO	IF CORRECT, PRESS [F1]YES
	IF YOU PRESS [F2] ANY TRANSACTION,	DDECC [E4] INIVOICE NUMBER OF [E3] ACCOUNT NUMBER
	RETREIVE BY:	PRESS [F1] INVOICE NUMBER OR [F2] ACCOUNT NUMBER
	INVOICE NUMBER ACCOUNT NUMBER	ENTER INVOICE NUMBER AND [ENTER]
	TRANSACTION DETAIL	OR ENTER CARD LAST 4 DIGITS AND [ENTER]
	YES	IF IT IS CORRECT, PRESS [F1]YES
	NO	, , , , , ,
-	•	<u> </u>